



## Installing Linoleum Over Warmboard

---

Linoleum is a floor covering made from solidified linseed oil in combination with flour or cork dust over a burlap or canvas backing. As an all natural product, linoleum offers many advantages and interfaces well with Warmboard.

### First and Always...

**Follow the specifications and installation recommendations provided by the linoleum manufacturer.**

The installation of underlayment is required over the Warmboard before the linoleum is installed. Care should be taken when fastening the underlayment to Warmboard because the tubing is obscured during this step. Warmboard recommends installing a 1/4" or 1/2" APA listed plywood underlayment with a sanded face. For complete installation details refer to "Engineered Wood Construction Guide" at [www.apawood.org](http://www.apawood.org). **Complete with installation of linoleum, follow all the manufactures guide-lines and specifications.**

**Important - The surface temperature of the installed linoleum should not exceed 85°.**